

CN565-15 PARTS LIST (by No.)

NO.	CODE	Description	NO.	CODE	Description
1	610560	BOLT M6X20 (Loctite 243)	58	330010	TRIGGER VALVE BUSHING
2	320940	BUSHING	59	510180	O-RING 5.8X1.9
3	410280	EXHAUST COVER	60	420640	PIN CAP ©
4	320930	EXHAUST FILTER (A)	61	320800	STEP PIN
5	320920	EXHAUST FILTER (B)	62	620390	FEED SPRING
6	110210	CYLINDER CAP	63	320960	CHECK TOE
7	610230	BOLT M6X30	64	420170	PIN CAP (A)
8	320910	SIDE PROTECTOR	65	210210	FEED PAWL
9	320900	PISTON STOP SEAT	66	320780	FEED PAWL PIN
10	410270	PISTON STOP	67	110220	NOSE
11	320890	WASHER	68	320850	DOOR PIN
12	620380	COMPRESSION SPRING	69	420630	DUST COVER
13	420610	HEAD VALVE PISTON	70	420620	GUARD COVER
14	510710	O-RING 54X3.1	71	210250	DOOR
15	510560	O-RING 41.2X2.65	72	420160	PIN CAP (B)
16	410260	HEAD VALVE SLEEVE	73	210230	CHECK PAWL (A)
17	410250	BUMPER	74	620300	CHECK SPRING (A)
18	520130	CYLINDER SEAL	75	620070	CHECK SPRING (B)
19	511010	O-RING 63.8X3.1	76	210240	CHECK PAWL (B)
20	510680	O-RING 50X2.65	77	320950	CHECK PAWL PIN
21	310180	CYLINDER	78	610110	BOLT M5X22
22	420600	CYLINDER RING	79	210270	LATCH
23	110200	BODY	80	620430	LATCH SPRING
24	640180	ROLL PIN 3X30	81	320990	STEP PIN
25	410460	HANDLE GRIP	82	610320	NUT M5 (Nylock)
26	323220	ROLL PIN 2X8	83	510640	O-RING 47.5X1.8
27	620370	SPRING	84	610220	BOLT M6X25 (Loctite 243)
28	110190	ADJUST BUTTON	85	510260	O-RING 9X1.8
29	320880	CONTACT PLATE	86	620340	SPRING
30	420590	TRIGGER BRACKET	87	320770	FEED PISTON
31	420580	TRIGGER	88	510390	O-RING 17X2.65
32	321810	STEP PIN	89	620420	FEED PISTON SPRING (A)
33	420950	PIN CAP	90	620410	FEED PISTON SPRING (B)
34	510220	O-RING 6.7X1.8	91	410240	FEED PISTON BUMPER
35	321740	SAFETY UPPER	92	320760	FEED PISTON CAP
36	620320	SPRING	93	630080	SNAP RING
37	420560	SAFETY UPPER GUIDE	94	410290	NOSE CAP
38	640020	ROLL PIN 2.5X10	95	110310	END CAP
39	420180	ADJUST DIAL	96	420540	FILTER
40	420650	SAFETY GUIDE	97	630110	SNAP RING
41	323120	SAFETY	98	420240	SPRING HOLDER (B)
42	320980	DRIVE BLADE (Loctite 262)	99	421570	MAGAZINE
43	310190	PISTON	100	610130	BOLT M5X30
44	510510	O-RING 37.5X3.55	101	321890	WASHER
45	620910	SNAP RING	102	320260	MAGAZINE PIN
46	510140	O-RING 5.15X1.8	103	620650	MAGAZINE SPRING
47	320970	ADJUSTER	104	420210	NAIL SUPPORT PLATE
48	640250	STRAIGHT PIN B3X15	105	420520	SPRING HOLDER (A)
49	510410	O-RING 18.3X2.65	106	420530	MAGAZINE COVER
50	420090	TRIGGER VALVE CAGE	107	620740	SPRING
51	510380	O-RING 16X1.8	108	520290	GASKET
52	420080	TIGGER VALVE CAP	109	323130	STRAIGHT PIN
53	320110	TIGGER STEM	110	410880	STRAIGHT PIN CAP
54	510030	O-RING 2.5X1.4	111	410060	RUBBER BUTTON
55	620050	SPRING			
56	510240	O-RING 8.6X1.9	P1	D320981	DRIVER UNIT
57	510210	O-RING 6.3X1.8	P2	T420091	TRIGGER VALVE

CN565-15 PARTS LIST (by Code)

NO.	CODE	Description	NO.	CODE	Description
28	110190	ADJUST BUTTON	37	420560	SAFETY UPPER GUIDE
23	110200	BODY	31	420580	TRIGGER
6	110210	CYLINDER CAP	30	420590	TRIGGER BRACKET
67	110220	NOSE	22	420600	CYLINDER RING
95	110310	END CAP	13	420610	HEAD VALVE PISTON
65	210210	FEED PAWL	70	420620	GUARD COVER
73	210230	CHECK PAWL (A)	69	420630	DUST COVER
76	210240	CHECK PAWL (B)	60	420640	PIN CAP ©
71	210250	DOOR	40	420650	SAFETY GUIDE
79	210270	LATCH	33	420950	PIN CAP
21	310180	CYLINDER	99	421570	MAGAZINE
43	310190	PISTON	54	510030	O-RING 2.5X1.4
53	320110	TIGGER STEM	46	510140	O-RING 5.15X1.8
102	320260	MAGAZINE PIN	59	510180	O-RING 5.8X1.9
92	320760	FEED PISTON CAP	57	510210	O-RING 6.3X1.8
87	320770	FEED PISTON	34	510220	O-RING 6.7X1.8
66	320780	FEED PAWL PIN	56	510240	O-RING 8.6X1.9
61	320800	STEP PIN	85	510260	O-RING 9X1.8
68	320850	DOOR PIN	51	510380	O-RING 16X1.8
29	320880	CONTACT PLATE	88	510390	O-RING 17X2.65
11	320890	WASHER	49	510410	O-RING 18.3X2.65
9	320900	PISTON STOP SEAT	44	510510	O-RING 37.5X3.55
8	320910	SIDE PROTECTOR	15	510560	O-RING 41.2X2.65
5	320920	EXHAUST FILTER (B)	83	510640	O-RING 47.5X1.8
4	320930	EXHAUST FILTER (A)	20	510680	O-RING 50X2.65
2	320940	BUSHING	14	510710	O-RING 54X3.1
77	320950	CHECK PAWL PIN	19	511010	O-RING 63.8X3.1
63	320960	CHECK TOE	18	520130	CYLINDER SEAL
47	320970	ADJUSTER	108	520290	GASKET
42	320980	DRIVE BLADE (Loctite 262)	78	610110	BOLT M5X22
81	320990	STEP PIN	100	610130	BOLT M5X30
35	321740	SAFETY UPPER	84	610220	BOLT M6X25 (Loctite 243)
32	321810	STEP PIN	7	610230	BOLT M6X30
101	321890	WASHER	82	610320	NUT M5 (Nylock)
41	323120	SAFETY	1	610560	BOLT M6X20 (Loctite 243)
109	323130	STRAIGHT PIN	55	620050	SPRING
26	323220	ROLL PIN 2X8	75	620070	CHECK SPRING (B)
58	330010	TRIGGER VALVE BUSHING	74	620300	CHECK SPRING (A)
111	410060	RUBBER BUTTON	36	620320	SPRING
91	410240	FEED PISTON BUMPER	86	620340	SPRING
17	410250	BUMPER	27	620370	SPRING
16	410260	HEAD VALVE SLEEVE	12	620380	COMPRESSION SPRING
10	410270	PISTON STOP	62	620390	FEED SPRING
3	410280	EXHAUST COVER	90	620410	FEED PISTON SPRING (B)
94	410290	NOSE CAP	89	620420	FEED PISTON SPRING (A)
25	410460	HANDLE GRIP	80	620430	LATCH SPRING
110	410880	STRAIGHT PIN CAP	103	620650	MAGAZINE SPRING
52	420080	TIGGER VALVE CAP	107	620740	SPRING
50	420090	TRIGGER VALVE CAGE	45	620910	SNAP RING
72	420160	PIN CAP (B)	93	630080	SNAP RING
64	420170	PIN CAP (A)	97	630110	SNAP RING
39	420180	ADJUST DIAL	38	640020	ROLL PIN 2.5X10
104	420210	NAIL SUPPORT PLATE	24	640180	ROLL PIN 3X30
98	420240	SPRING HOLDER (B)	48	640250	STRAIGHT PIN B3X15
105	420520	SPRING HOLDER (A)			
106	420530	MAGAZINE COVER	P1	D320981	DRIVER UNIT
96	420540	FILTER	P2	T420091	TRIGGER VALVE