


NP3523 Parts Kits List

Rev 07/24/2015

ICB No. 98674 (NP3523K1) O-ring/Gasket Kit contains:


#2	90058	Cap O-ring 24X2	1	#10	90055	O-Ring 4.5X1.5	1
#3	90049	Piston O-ring 13.8X2.4	1	#12	90005	O-ring 7X1	1
#5	90058	O-ring 24X2	1	#13	90009	O-ring 1.8X1.2	1
#8	18060-1	Trigger Valve Set	1	#15	90007	O-ring 17.5X1.5	1
				#29	90024	O-ring 5.5X1.5	1

ICB No. 98675 (NP3523K2) Piston/Driver Assembly Kit contains:




#3	90049	Piston O-ring 13.8X2.4	1
#4	28090	Piston Unit	1
#60	22370	Drive Guider	1

ICB No. 98676 (NP3523K4) Trigger Valve Assembly with Trigger Kit contains:



#8	18060-1	Trigger Valve Set	1
#9	18070	Valve Spring	1
#10	90055	O-Ring 4.5X1.5	1
#11	18081	Valve Seat	1
#12	90005	O-ring 7X1	1
#13	90009	O-ring 1.8X1.2	1
#14	18100	Trigger Valve Stem	1
#15	90007	O-ring 17.5X1.5	1
#16	18120	Trigger Valve Cover	1
#25	22320	Pin	2
#55	96005	Pin	1
#56	22330	Trigger	1
#57	22340	Secondary Trigger	1
#59	90010	O-ring 1.5X1	1

ICB No. 98677 (NP3523K8) Feeder Kit contains:



45	22220	Spring Guide Seat A	1
46	22230	Spring Guide	6
47	22260	Pusher A	1
48	22280	Lock Out Spring	1
49	22290	Lock Out Pin	1
50	22240	Spring Guide Seat B	1
51	28080	Spring	6
52	22270	Pusher Spring	1
53	22300	Pusher L	2
54	22310	Pusher C	4